



■ Main Unit




70AS-03S
70AS-05S

③




70AS-03S
70AS-05S


■ CRT Socket and Control Unit



70AS-03S
70AS-05S

70AS-03S
70AS-05S

Note: The symbol  means a resistor of 1/16 W.




HARP

70AS-03S
70AS-05S


70AS-03S
70AS-05S

MODELS 70AS-03S and 70AS-05S SCHEMATIC DIAGRAM


IF and TEXT and IGR Unit



IGR (70AS-05S)



IGR (70AS-03S)




70AS-03S
70AS-05S

Note: The symbol means a resistor of 1/16 W.

[illegible]


| | | | |
|---|---|---|---|
| 1 | 2 | 3 | 4 |
|---|---|---|---|



70AS-03S
70AS-05S

70AS-03S
70AS-05S

M




70AS-03S
70AS-05S

70AS-03S
70AS-05S

MODEL 70AS-05S SCHEMATIC DIAGRAM

AV Unit



70AS-03S
70AS-05S

AM

